



Unpacking your SpaBerry

1.

Start with your SpaBerry standing upright, please take note of the "This side down" sticker. At the top slice through the plastic from left to right, then at the right hand side slice the wrapping all the way down to the bottom. Now pull away all of the plastic.



2.

Pull the black strap at the bottom away from the box and cut it. Now take the bottom flaps and unfold them; continue this process to all 4 sides at the bottom. Once complete, grab the bottom of the box and lift it up over your SpaBerry. Discard the box to the side.



3.

Please take note of the location of your SpaBerry Starter Kit attached to the side of your SpaBerry. With one person on each side, give the SpaBerry a push towards the bottom of the unit. With 2 people now on the same side after tilting, slowly lower your SpaBerry to the ground.



4.

Cut the outer most piece of shrink wrap that is currently holding the cardboard to the tub, and remove the cardboard. While pulling the wrap away from the tub, cut the remaining shrink wrap and walk around the tub while collecting it. Continue this process again for the foam wrap.



Unpacking your SpaBerry Continued...

5.

At this point you will be able to remove the cover freely. Please make note of the hardware wrapped around one of the cover straps. Again by pulling the shrink wrap away from the tub, cut the wrap top to bottom and then walk around the spa collecting it. Now remove all blue packing finish tape by walking around your SpaBerry.



Find the GFCI power cord and remove the protective wrap carefully. Locate and remove all stickers, please be sure to review each one, and place aside in a safe place for future reference.

6.



7.

Turn the power cord casing counter clockwise to loosen, and then pull out desired cord length to reach your power outlet. Remove the filter canister, and then pull out the wrapped paper BerryFilter; remove the plastic wrapping, and then return to the filter area and screw in clockwise until secure.



8.

Congratulations! You're now ready to proceed to the next setup step of installing your BerrySeal SpaBerry Cover, and then filling your SpaBerry with water!